

Modeling of the Test Fixtures to Improve the HBC Channel Interpretation

M. D. Pereira, G. A. Alvarez, F. R. de Sousa
Radiofrequency Research Group



UNIVERSIDADE FEDERAL
DE SANTA CATARINA

Presentation Outline



- **Human Body Communication - HBC**
- **HBC Channel modeling**
 - Primary channel model
- **HBC Channel measurements**
 - Measurement system and results
- **Test Fixture modeling**
 - Extended Model
- **Final Considerations**


Presentation Outline



- **Human Body Communication - HBC**
- HBC Channel modeling
 - Primary channel model
- HBC Channel measurements
 - Measurement system and results
- Test Fixture modeling
 - Extended Model
- Final Considerations

HBC – Human body communication

- PAN/HBC/IBC/BCC - Thomas G. Zimmerman [Zimmerman, 1995].
- Electrostatic coupling to the body using electrodes (galvanic e capacitive).




Zimmerman, T. G., "Personal Area Networks: Near-field intra-body communication,"
M.S. Thesis, MIT Media Laboratory, Cambridge, MA, Sept. 1995.

HBC – Human body communication



- PAN/HBC/IBC/BCC - Thomas G. Zimmerman [Zimmerman, 1995].
- Electrostatic coupling to the body using electrodes (galvanic e capacitive).
- Low frequency operation (<100 MHz).
- Advantages over other BAN options:
 - Higher data security.
 - Higher coexistence.
 - Lower channel attenuation.
 - Lower power consumption.



Zimmerman, T. G., "Personal Area Networks: Near-field intra-body communication,"
M.S. Thesis, MIT Media Laboratory, Cambridge, MA, Sept. 1995.

Capacitive HBC characterization and modeling



- Required for link budget analysis (Tx output power, Rx sensitivity, operating frequency).
- Literature review:
 - Different author find different attenuation levels and frequency profile.
 - Most models cannot fully reproduce the measured channel frequency profiled.
 - Obtained models are not complete or where not validate correctly.
 - Correct channel path is not preserved.
 - Neglecting of the influence of test fixture.

Presentation Outline




- Human Body Communication - HBC
- **HBC Channel modeling**
 - Primary channel model
- HBC Channel measurements
 - Measurement system and results
- Test Fixture model
 - Extended Model
- Final Considerations

Primary channel




- Primary channel partitioning:
 - Intrinsic channel.
 - Extrinsic channel.
- Secondary channel: external structures (environment and test fixture).



Intrinsic channel

- Network based on unit blocks equivalent circuit offers good compact alternative [Xu *et al*, 2011].





R. Xu; H. Zhu; J. Yuan, "Electric-Field Intrabody Communication Channel Modeling With Finite-Element Method," Biomedical Engineering, IEEE Transactions on, March 2011

Extrinsic channel




- Return capacitances: empirical exp. and 3D EM simulations EM 3D.



Extrinsic channel



- Body leakage capacitances.
- Inter-electrode and electrode skin impedances.





Primary channel



R_{arm}	65 Ω	R_{chest}	500 Ω
C_{arm}	25 pF	C_{chest}	3.5 pF
C_{leak-a}	0.7 pF	R_{torso}	600 Ω
C_{leak-t}	15 pF	C_{torso}	4 pF
C_{injec}	5.5 pF	R_{injec}	250 Ω





C_{ret}	870 fF	C_e	11.3 pF
C_{x-20}	25 fF	C_{x-30}	16 fF
C_{x-140}	1.25 fF	-	-



Primary channel model



- High pass profile.
- Low frequency dependence on distance.
- Attenuation levels between 50-100 dB.



Presentation Outline




- Human Body Communication - HBC
- HBC Channel modeling
 - Primary channel model
- **HBC Channel measurements**
 - Measurement system and results
- Test Fixture modeling
 - Extended Model
- Final Considerations

Measurement system




- R&S ZVB VNA.
- Baluns FTB-1-1.
- Cables RG 316.
- 2 x 2 cm² electrodes.
- SOLT calibration at the balun's transitions.



Channel measurements




- Pass band profile.
- Independence of d in lower frequencies.
- Attenuation levels between 10-50 dB.



Measurements and model comparison



- 30 cm propagation distance.
- Differences on freq. profile.
- Over 45 dB higher attenuation.
- Balun's effect [Sakai et al, 2013].



Sakai, J.; Lin-Sheng Wu; Hu-Cheng Sun; Yong-Xin Guo, "Balun's effect on the measurement of transmission characteristics for intrabody communication channel," Microwave Workshop Series on RF and Wireless Technologies for Biomedical and Healthcare Applications (IMWS-BIO), 2013 IEEE MTT-S International , vol., no., pp.1,3, 9-11 Dec. 2013.

Presentation Outline




- Human Body Communication - HBC
- HBC Channel modeling
 - Primary channel model
- HBC Channel measurements
 - Measurement system and results
- **Test Fixture modeling**
 - Extended Model
- Final Considerations

Test fixture modeling





- DUT and test fixture transitions.
 - Modified cables transitions model.
 - Baluns: model extraction.



Extended model

R_{arm}	65 Ω	R_{chest}	500 Ω
C_{arm}	25 pF	C_{chest}	3.5 pF
C_{leak-a}	0.7 pF	R_{torso}	600 Ω
C_{leak-t}	15 pF	C_{torso}	4 pF
C_{injec}	5.5 pF	R_{injec}	250 Ω




C_{iw}	27.2 pF	L_t	420 nH	L_t	6 nH
C_{dis}	12.3 pF	L_m	200 μ H	C_t	-

C_{ret}	870 fF	C_e	11.3 pF
C_{x-20}	25 fF	C_{x-30}	16 fF
C_{x-140}	1.25 fF	-	-

Extended model




- Reproduces the band pass profile.
- Low frequency independence of d .
- Around 45 dB lower attenuation.



Measurements and Extended model comparison



- Good extended model fit below 70 MHz
- Differences < 5.5 dB.



Presentation Outline



- Human Body Communication - HBC
- HBC Channel modeling
 - Primary channel model
- HBC Channel measurements
 - Measurement system and results
- Test Fixture modeling
 - Extended Model
- **Final Considerations**

Final Considerations



- Contributions:
 - Proposal of a systematic primary channel partitioning that facilitates HBC understanding and modeling.
 - Proposal of extended model that includes the test fixture.
 - Verification of test fixture influences.
 - Validation of primary channel model and identification of challenges for transceiver design.
- Ongoing studies:
 - Methodology to de-embed the test fixture from measurements.

Thank You



UNIVERSIDADE FEDERAL
DE SANTA CATARINA